

# PREMIUM CARGO STRAP WINDER



## INSTRUCTIONS FOR OPERATION

- 1) SECURE BRACKET ONTO FLATBED RUB RAIL & INSERT HANDLE INTO PIN
- 2) INSERT STRAP END INTO WINDER & ROTATE
- 3) PULL STRAP AND HANDLE OFF BRACKET
- 4) PULL HANDLE OFF OF ROLLED STRAP
- 5) STRAP IS READY FOR STORAGE

STRAP WINDER QUICKLY ASSISTS IN WINDING WINCH STRAPS INTO ROLLS FOR STORAGE



## ZINC PLATED STEEL CONSTRUCTION

### SPECIFICATIONS

*Designed to clip into trailer stake pocket or side rail for use. Unit package size: 10" x 12" x 1 5/8"  
Unit weight: 2.7 lbs*

### DURABLE

*Zinc plated steel construction for maximum durability.*

